



## Current URL Commands



### Show

Action: Make the scanner app visible  
Parameters: None  
Example: [mxs-88:show](#)



### Hide

Action: Hide the scanner app  
Parameters: None  
Example: [mxs-88:hide](#)



### Pos (or position)

Action: Set the scanner app position and, optionally, the size  
Parameters: Left, Top, Width, Height, Width & Height are optional  
Note: The size is limited to about 500 x 500  
Examples: [mxs-88:position=50,50,200,200](#)  
[mxs-88:pos=100,100](#)



### Size

Action: Set the scanner size  
Parameters: Width, Height  
Note: The size is limited to about 500 x 500  
Example: [mxs-88:size=400,300](#)



### Scan

Action: Start the scan operation  
Parameters: None  
Example: [mxs-88:scan](#)



### Stop

Action: Stop the scan operation  
Parameters: None  
Example: [mxs-88:stop](#)



### Exit

Action: Exit the scanner app  
Parameters: None  
example: [mxs-88:exit](#)



### Combining commands

Action: Commands can be combined  
Examples: [mxs-88:pos=50,50,400,400/show/scan](#)  
[mxs-88:stop/hide](#)